



## PWCキット-ロッドとカップホルダーのサポート

製品 :	Sea-Doo_watercraft
プロジェクト番号 :	487803486
インストラクションシートP/N :	487803486
改訂番号 :	
改訂日 :	
対象アイテム :	ロッドとカップホルダーのサポート

このドキュメントでは、次の記号を使用できます。

### ⚠ 警告

回避しないと、死亡または重傷を負う可能性のある危険な状況を示します。

**⚠ 注意 :** 回避しないと、軽傷または中程度の傷害を引き起こす可能性のある危険な状況を示します。

**通知** 従わないと、車両のコンポーネントやその他の資産に重大な損傷を与える可能性のある指示を示します。

### ⚠ 警告

- このキットは、特定の該当するモデル専用設計されています（認定BRPディーラーがモデルを確認します）。販売されたユニット以外のユニットにはお勧めしません。
- キットのインストールにテンプレートが必要な場合は、テンプレートが縮尺どおりであることを確認してください。
- 分解/組み立ての際にロック装置（ロックタブ、セルフロックファスナーなど）の取り外しが必要な場合は、必ず新しいものと交換してください。
- トルクレンチの締め付け仕様を厳守する必要があります。
- 電動工具を使用するときは、常に目の保護具と適切な手袋を着用してください。
- 特に指定のない限り、車両で操作を行うときはエンジンをオフにする必要があります。

### ⚠ 警告

この取扱説明書には、エンドユーザー専用の重要な安全情報や操作説明書が含まれている場合があります。キットの部品番号と、このキットに含まれている取扱説明書を必ずお客様に提供してください。お客様がアクセサリの適切な使用に必要なすべての情報にアクセスできることを確認します。


**NOTE:** USE TIGHTENING TORQUES IN THE FOLLOWING TABLE IF NOT OTHERWISE SPECIFIED.

	GRADE			
	5.8	8.8	10.9	12.9
M4	1.8 ± 0.2 N•m (16 ± 2 lbf•in)	2.8 ± 0.2 N•m (25 ± 2 lbf•in)	3.8 ± 0.2 N•m (34 ± 2 lbf•in)	4.5 ± 0.5 N•m (40 ± 4 lbf•in)
M5	3.3 ± 0.2 N•m (29 ± 2 lbf•in)	5 ± 0.5 N•m (44 ± 4 lbf•in)	7.8 ± 0.7 N•m (69 ± 6 lbf•in)	9 ± 1 N•m (80 ± 9 lbf•in)


M6	7.5 ± 1 N•m (66 ± 9 lbf•in)	10 ± 2 N•m (89 ± 18 lbf•in)	12.8 ± 2.2 N•m (113 ± 19 lbf•in)	16 ± 2 N•m (142 ± 18 lbf•in)
M8	15.3 ± 1.7 N•m (135 ± 15 lbf•in)	24.5 ± 3.5 N•m (18 ± 3 lbf•ft)	31.5 ± 3.5 N•m (23 ± 3 lbf•ft)	40 ± 5 N•m (30 ± 4 lbf•ft)
M10	29 ± 3 N•m (21 ± 2 lbf•ft)	48 ± 6 N•m (35 ± 4 lbf•ft)	61 ± 9 N•m (45 ± 7 lbf•ft)	73 ± 7 N•m (54 ± 5 lbf•ft)
M12	52 ± 6 N•m (38 ± 4 lbf•ft)	85 ± 10 N•m (63 ± 7 lbf•ft)	105 ± 15 N•m (77 ± 11 lbf•ft)	128 ± 17 N•m (94 ± 13 lbf•ft)
M14	85 ± 10 N•m (63 ± 7 lbf•ft)	135 ± 15 N•m (100 ± 11 lbf•ft)	170 ± 20 N•m (125 ± 15 lbf•ft)	200 ± 25 N•m (148 ± 18 lbf•ft)
M16	126 ± 14 N•m (93 ± 10 lbf•ft)	205 ± 25 N•m (151 ± 18 lbf•ft)	255 ± 30 N•m (188 ± 22 lbf•ft)	305 ± 35 N•m (225 ± 26 lbf•ft)
M18	170 ± 20 N•m (125 ± 15 lbf•ft)	273 ± 32 N•m (201 ± 24 lbf•ft)	330 ± 25 N•m (243 ± 18 lbf•ft)	413 ± 47 N•m (305 ± 35 lbf•ft)

The illustrations in this document show typical construction of the different assemblies and may not reproduce the full detail or exact shape of the parts; however, they represent parts that have the same or similar function. Installation time is approximately 0.6 hour.

## REQUIRED TOOLS

Required Tool		Use
T1	Drill bit 9.5 mm (3/8 in)	 To drill side panel

## PARTS TO BE INSTALLED




**NOTE:** Kit (P/N 295100948) is used on LH side, while kit (P/N 295100949) is used on RH side.

ITEM	DESCRIPTION	Part number	QTY
P1	LH Rod Support Adaptor	291005498	1
	RH Rod Support Adaptor	291005481	1
P2	LH Mounting Base	269800997	1
	RH Mounting Base	269800998	1
P3	10-14 x 7/8 Hexagonal Screw	250001087	5


# INSTRUCTIONS

## Vehicle Preparation


Remove both front and rear seats.



Open both storage bin and glove box.




Remove hardware.



**NOTE:** LH side shown, RH side similar.

Remove side panel.




Step 1.: Lift  
Step 2.: Pull rearward

## Part Installation


### **MY21 and Up**

On the side panel , locate the five (5) molded mark and drill using [T1]9.5 mm (3/8 in) drill bit.




### **MY18 to MY20**

Install both templates as shown, mark location and drill using [T1]9.5 mm (3/8 in) drill bit.




TEMPLATE A (UPPER)




TEMPLATE B (LH, LOWER) OR TEMPLATE C (RH, LOWER)

### **All Models**

Install rod support adaptor [P1] and mounting base [P2].



Secure using 10-14 x 7/8 hex. screw [P3]. Tighten to specification.



#### tightening torque

10-14 x 7/8 hex. screw [P5]

$5.5 \pm 0.5 \text{ N}\cdot\text{m}$  ( $49 \pm 4 \text{ lbf}\cdot\text{in}$ )

サイドパネルを再度取り付け、M6トルクスネジを仕様どおりに締めます。

#### 締め付けトルク

M6トルクスネジ

$4.5 \pm 0.5 \text{ N}\cdot\text{m}$  ( $40 \pm 4 \text{ lbf}\cdot\text{in}$ )

#### ⚠ 警告

- 道路でPWCを追跡する前に、必ず釣り竿やボトルをサポートから取り外してください。緩んだ物体は落下して道路の危険になる可能性があります。
- 高速で航行している間は、常に釣り糸を確保してください。不適切に固定された釣り針は、運転手や乗客に害を及ぼす可能性があります。

#### ⚠ 注意 :

- 水がかき混ぜられたり、状態が悪化したりした場合は、必ずボトルをホルダーから取り外してください。ボトルが落下したり、発射物になり、運転手や乗客に危害を加える可能性があります。
- 常に適切なサイズのタイトフィットボトルを使用してください。ボトルが小さすぎたり大きすぎたりすると、うまくフィットせずに脱落したり、発射物になって運転手や乗客に危害を加えたりする可能性があります。

[Templates.pdf](#)